When you start up the program, it will open up to the following screen:

•	Edys-HSAUSA-1.8	8				
File	e Connection Exit					
	BEST BY	12/3	1/09	DATE CO	DE ACTIVE	Rest By must be sell
· · · · · »	RESET RUN TI	ME 08.	34	LANE COD	E INACTIVE	
Ş	STATUS	NAME	BEST BY	RUN TIME	OPTION FIELD	CONTROLLER TRAFFIC
		A01	12/31/09	08.34	010	<u>•</u>
		A02	12/31/09	08.34	010	<u>•</u>
		A03	12/31/09	08.34	010	▼
		A04	12/31/09	08.34	010	•
		A05	12/31/09	08.34	010	<u>•</u>
		A06	12/31/09	08.34	010	
		A07	12/31/09	08.34	010	
14		A08	12/31/09	08.34	010	

To ensure that the system will operate correctly, the operator will need to go into the set up screen, using the File Menu. Click on File at the top left of the screen and then select Setup:

Edys-HSAUSA-1.8									
File Connection Exit									
	Setup UDE T BY 12/31/09			DE ACTIVE	Rest By must be sell				
RESET RUN T	IME 08	10	LANE COD	E INACTIVE					
STATUS	NAME	BEST BY	RUN TIME	OPTION FIELD	CONTROLLER TRAFFIC				
	A01	12/31/09	09.13	010		•			
	A02	12/31/09	09.13	010		•			
	A03	12/31/09	09.13	010					
	A04	12/31/09	09.13	010		•			
	A05	12/31/09	09.13	010					
	A06	12/31/09	09.13	010					
	A07	12/31/09	09.13	010					
	A08	12/31/09	09.13	010					
	<u>//</u>								

This will bring up the following screen:

Edys-HSAU	ISA-1.8				
File Connection	i Exit				
Setup					
		Pr	inter Configuration		
	Name	On Line	IP Address	Option	Runtime Parameters
	A01	X	192.168.001.131	010	Simulate Printers
	A02	X	192.168.001.148	010	IP Address Port
	A03	X	192.168.001.134	010	
	A04	X	192.168.001.135	010	127.0.0.1 3000
	A05	X	192.168.001.136	010	
	A06	X	192.168.001.137	010	Dis a Circulator
	A07	X	192.168.001.138	010	
	A08	X	192.168.001.139	010	
					Line Code Message Line Sage
					Miscellaneous
L	_				Date Format
ſ	Manual Mo	de			mm/dd/yy
				•	Render date as all caps
		Send	Clear		Edit INI File

There are several things that need checking on this screen in order for the system to operate correctly:

Edys-HS	AUSA-1.8					
File Connect	tion Exit		IP Address to co	nform		
- Setup	Setup Lane Number		ON LINE= X with the Mini Touch OFFLINE = Controller		Option = Line 10	
		/	/		/	
		/ Pr	inter Configuration	/		
	Name	On Line	IP Address /	Option	Runtime	Parameters
	A01	X	192.168.001.131	010		Must Remain at 3000
	A02	X	192.168.001.148	010		ID Addrose Port
	A03	X	192.168.001.134	010		IF Addless Fold
	A04	X	192.168.001.135	010		127.0.0.1 3000
	A05	X	192.168.001.136	010		
	A06	X	192.168.001.137	010		
	A07	X	192.168.001.138	010		Start Simulator
	A08	X	192.168.001.139	010		
	Manual Moo	le Send	Clear		Miscella	Date Code bestby Message lane Must read lane aneous Date Format m/dd/yy ✓ Render date as all caps Edit INI File

The Lane Number should be set up at A01 – A09 for the East Machine and B01-B09 for the West Machine:

There is an option to allow some or all of the Lanes to run at the same time.

If it is required that a particular lane does not run, then HIGHLIGHT the X on the ON LINE column for the correct Lane and press Delete, using the Delete Key on the keyboard.

The IP Address on the Configuration must match that on the Mini Touches. These have been set as follows

MINITOU	CH IP ADDRESSES
UNIT	IP
NUMBER	ADDRESSES
EAS	TMACHINE
A01	192.168.0 <mark>01.1</mark> 01
A02	192.168.001.102
A03	192.168.001.203
A04	192.168.001.104
A05	192.168.001.105
A06	192.168.001.206
A07	192.168.001.107
A08	192.168.001.208
WES	TMACHINE
B01	192.168.001.101
B02	192.168.001.102
B03	192.168.001.203
B04	192.168.001.104
B05	192.168.001.105
B06	192.168.001.206
B07	192.168.001.107
B08	192.168.001.208

All other items should remain as they are factory settings, and should only be changed at the direction of Dartronics Technical Support.

After confirming the Set Up settings are correct, return to the Operate Screen, by using the File/Operate at the top left of the screen.

Edys-HSAUSA-1.8 File Connection Exit	1 Edys-HSAUSA-1.8								
BEST BY	12/31	1/09	DATE CO	DE ACTIVE	Bust Exemption soft				
RESET RUN T	IME 08.	34	LANE COD	E INACTIVE					
STATUS	NAME	BEST BY	RUN TIME	OPTION FIELD	CONTROLLER TRAFFIC				
	A01	12/31/09	08.34	010	<u>•</u>				
	A02	12/31/09	08.34	010					
	A03	12/31/09	08.34	010	<u>_</u>				
	A04	12/31/09	08.34	010					
	A05	12/31/09	08.34	010	· · · · · · · · · · · · · · · · · · ·				
	A06	12/31/09	08.34	010					
	A07	12/31/09	08.34	010					
	A08	12/31/09	08.34	010	•				
			<i>I</i>						

To set the system into Operation Mode the following Steps must be followed:

Set the Best BY Date. It is programmed into the system, that while in "DATE CODE ACTIVE" MODE" until the Best By Date is set, the "SEND WRAPPERS" Button is inactive.

To do this, click on

BEST BY

and a Date Calendar will open up

Simply select the Date that is required to use as a sell by

3 Edys-I	ISAUS	A-1.8	Į.							
File Conn	ection	Exit								
BEST BY 12/31/09				/31/0	9	DATE CO	DE ACTIVE			
Sun	December 2009 Sun Mon Tue Wed Thu Fri Sat					LANE COD	E INACTIVE	Best By must be set		
6	7	1 8	2	3 10	4 11	5 12	19: 44 W			
13	14	15	16	17	18	19	BEST BY	RUN TIME	OPTION FIELD	CONTROLLER TRAFFIC
20	21 28 4	22 29 5	23 30 6	31	25 1 8	26 2 9	12/31/09	08.37	010	
0	Tod	ay: 12	2/31/	2009						
				A02	1		12/31/09	08.37	010	

You will notice that the SEND WRAPPERS button notifies the Operator that the Best By Date must be set.

The next stage of the procedure is to "reset" the run time.

Edys-HSAUSA-1.8 Connection Exit						
BEST BY	12/31	/09	DATE CO	DE ACTIVE		
RESET RUN TIN	4E 08.3	34	LANE CODE INACTIVE		SEND WRAPPERS	
STATUS	NAME BEST BY		RUN TIME OPTION FIELD		CONTROLLER TRAFFIC	
	A01	12/31/09	08.38	010		
	A02	12/31/09	08.38	010		
he run time needs resetting, then Clicking on the RESET RUN TIME and the time will be set to the current time.						
at is all that needs to be set prior to starting the print.						
e operator should t	hen verify that tl	ne power is on to	all of the Mini To	ouches, and then sh	ould press SEND WRAPPERS	

After SEND WRAPPERS is done the screen should look like:

8	Edys-HSAUSA-1.8									
File	File Connection Exit									
2	BEST BY	12/31	1/09	DATE CO	DE ACTIVE	SEND WRAPPERS				
	RESET RUN TI	ME 08.	40	LANE COD	E INACTIVE					
	STATUS	NAME	BEST BY	RUN TIME	OPTION FIELD	CONTROLLER TRAFFIC				
		A01	12/31/09	08.40	010	0.000:Idle "Load Printer" Complete				
3		A02	12/31/09	08.40	010	0.000:Idle "Load Printer" Complete				
		A03	12/31/09	08.40	010	0.000:Idle "Load Printer" Complete				
		A04	12/31/09	08.40	010	0.000:Idle "Load Printer" Complete				
2		A05	12/31/09	08.40	010	0.000:Idle "Load Printer" Complete				
		A06	12/31/09	08.40	010	0.000:Idle "Load Printer" Complete				
		A07	12/31/09	08.40	010	0.000:Idle "Load Printer" Complete				
		A08	12/31/09	08.40	010	0.000:Idle "Load Printer" Complete				
			5							

The STATUS Colum signifies the current connected status of the particular lane.

If any of the Status Boxes are YELLOW, this signifies that the printer has manually been taken OFFLINE in the SET UP screen.

If any of the Status Boxes are RED, this signifies that for some reason (stated below) that there is NO CONNECTIVITY between the software and the Mini Touch on that Lane. If this occurs, please go to the Trouble shooting Section at the end of the Information Sheet.

On the right hand side of the screen, there is a "Controller Traffic" Colum.

This shows the 12 most recent commands sent down to the Mini Touch with the software.

When Send Wrappers is sent, and the operator clicks on the drop down arrow to the right, the following information will appear.

	Edys-HSAUSA-1.8						
File	Connection Exit						
, v	BEST BY	12/3	1/09	DATE CODE ACTIVE			
	RESET RUN TI	ME 10.	23				SEND WRAPPERS
	STATUS	NAME	BEST BY	RUN TIME	OPTION FIELD		CONTROLLER TRAFFIC
		A01 12/31/09	12/31/09	11.03	010	0.000:	Idle "Load Printer" Complete!
		A02	12/31/09	11.03	010	0.000 0.000 0.000 0.000 0.000	<pre>:=> "OBJ:lane;TEX=A01#" :<= "RES:0;Transmission OK#" :=> "OBJ:date;TEX=12/31/09#" :<= "RES:0;Transmission OK#" :=> "CHD:F;bestby#"</pre>
1		A03	12/31/09	11.03	010	0.000	:<= RES:0;Transmission OK# :=> CMD:U;Edys-HSAUSA-1.8;D0 ¥

This is for information only and cannot be changed, however if trouble shooting with Dartronics Technical Support, it may be required to read out the information in this drop down. Nothing can be changed in the drop down.

The system is programmed to update the RUN Time that is printed onto the wrapper every minute while the software is running. It can be noticed that the Controller Traffic screen will change whenever that occurs.

🛱 Edy	ys-HSAUSA-1.8					
File C	Connection Exit					
	BEST BY	12/3	1/09	DATE CO	DE ACTIVE	
RE	ESET RUN TIM	E 08.	40	LANE COD	E INACTIVE	SEND WITH FEND
	STATUS	NAME	BEST BY	RUN TIME	OPTION FIELD	CONTROLLER TRAFFIC
		A01	12/31/09	08.43	010	0.000:<= "RES:0;Transmission OK#" - 0.000:<= "RES:0;Transmission OK#" -
		A02	12/31/09	08.43	010	60.344:=> OBJ:time;TEX=08.43# 0.016:<= RES:0;Transmission OK# 60.047:=> OBJ:time;TEX=08.42# 0.000:<= RES:0;Transmission OK# 51.820:=> OBJ:time;TEX=08.41#
		A03	12/31/09	08.43	010	0.000:Printer Loaded!

Again, nothing can be changed in this drop down.

Procedure for Changing the Ink Cartridge while the printer is running.

On the carts containing the Mini Touch units there are 2 Stack Lights comprising of 4 individual lights each, which are the LOW INK alarm warning beacons for the 8 Mini Touches. If a LOW INK ALARM light is illuminated during the printing process then the Ink Cartridge is at 4% of the 42ml capacity (1.68ml) and should be changed within a short time. If this is not changed then the wrapper will not be printed.

The procedure for the Ink Cartridge change is as follows.

1) Disconnect the printer

To do this Right Click on the Status Colum of the appropriate Lane

Edys-HSAUSA-1.8					
File Connection Exit					
BEST BY	12/3	1/09	DATE CO	DE ACTIVE	SEND WRADDEDS
RESET RUN TI	IME 08.	40	LANE COD	E INACTIVE	
STATUS	NAME	BEST BY	RUN TIME	OPTION FIELD	CONTROLLER TRAFFIC
	A01	12/31/09	08.45	010	0.000:<= "RES:0;Transmission OK#" -
Set Or	nline				
Set Or		12/31/09	08.45	010	
Conne Discon	necti				U.UUU:<= "RES:U;Transmission OK#" -
Start F Stop P	Printer Printer	12/31/09	08.45	010	0.000:<= "RES:0;Transmission OK#" -
Reset	Run Count				
Reset	Ink Level	12/31/09	08.45	010	0.000./= "RFS-0-Transmission OF#" -

2) Select Disconnect

Edys-HSAUSA-1.8	3				
File Connection Exit	• •				
BEST BY	12/3	1/09	DATE CO	DE ACTIVE	
RESET RUN T	IME 08	18.40 LANE C		DE INACTIVE	SEND WHAPPERS
STATUS	NAME	BEST BY	RUN TIME	OPTION FIELD	CONTROLLER TRAFFIC
	A01	12/31/09	08.45	010	0.000:<= "RES:0;Transmission OK#"
Set O	nline				
Set O	ffline	12/31/09	08.45	010	
Connect Disconnect **					0.000:<= "RES:0;Transmission OK#" -
Start Stop I	Printer Printer	12/31/09	08.45	010	0.000:<= "RES:0;Transmission OK#" -
Reset	: Run Count				
Reset Ink Level		12/31/09	08.45	010	

3) Replace the cartridge on the Pen Stall

4) Click on RESET INK level.

Edys-HSAUSA-1.8						
ile Connection Exit						
BEST BY	12/3	1/09	DATE CO	DE ACTIVE		
RESET RUN TI	ME 08	.40	LANE CODE INACTIVE		SEND WHAPPERS	
STATUS	NAME	BEST BY	RUN TIME	OPTION FIELD	CONTROLLER TRAFFIC	
	A01	12/31/09	08.45	010	0.000:<= "RES:0;Transmission OK#"	
Set Offi Connec Disconn	ine ti iect	12/31/09	08.45	010	0.000:<= "RES:0;Transmission OK#" -	
Start Pr Stop Pri Reset R	inter inter tun Count	12/31/09	08.45	010	0.000:<= "RES:0;Transmission OK#" -	
Reset I	nk Level **	12/31/09	08.45	010	0.000:<= "RES:0:Transmission OK#"	

When the RESET INK Level is selected the Software automatically reconnects to the Mini Touch that was disconnected manually and sends down the correct print information, including the current run time. Simultaneously, the Mini Touch internal ink level monitor is reset to 100% (42ml))

NOTES:

It is imperative that when replacing a cartridge that a FULL cartridge is used, otherwise the system will "believe" that the cartridge is full, even though it is not, and the message will not be printed if the Pen runs out of ink.

If is necessary to simply reseat the old cartridge, do not select "Reset Ink Level", but use "Connect instead from the same right click menu. This will send the print information, including the correct run time down to the Mini Touch, but will not reset the ink level.

Ending the Program

In an attempt to ensure that the printers are shut down correctly, the software has a failsafe shut down method that will stop the printers from printing and then close down the software correctly.

The procedure for shut down prior to maintenance, cleaning or end of shift (or any other reason) is as follows

1) Disconnect the printers via the software, by clicking on Connection, then selecting Disconnect

dys-HSAUSA-1.8					
Connection Exit					
Connect Disconnect	12/3	1/09	DATE CO	DE ACTIVE	
ESET RUN TI		.40	LANE COE	E INACTIVE	SEND WHAPPERS
STATUS	NAME	BEST BY	RUN TIME	OPTION FIELD	CONTROLLER TRAFFIC
	A01	12/31/09	08.56	010	0.000:<= "RES:0;Transmission OK#"
	A02	12/31/09	08.56	010	0.000:<= "RES:0;Transmission OK#"
	A03	12/31/09	08.56	010	0.000:<= "RES:0;Transmission OK#"

After this is carried out, all printers that are enabled will be disconnected. The screen will show as follows

S Edys-HSAUSA-1.8									
File	File Connection Exit								
2	BEST BY 12/31/09		1/09	DATE CO	DE ACTIVE	SEND WRAPPERS			
RESET RUN TIME 08.40		40	LANE COD	E INACTIVE					
	STATUS	NAME	BEST BY	RUN TIME	OPTION FIELD	CONTROLLER TRAFFIC			
23		A01	12/31/09	08.57	010	0.125:Disconnect Complete!			
		A02	12/31/09	08.57	010	0.125:Disconnect Complete!			
		A03	12/31/09	08.57	010	0.125:Disconnect Complete!			
32		A04	12/31/09	08.57	010	0.125:Disconnect Complete!			
		A05	12/31/09	08.57	010	0.125:Disconnect Complete!			
1		A06	12/31/09	08.57	010	0.125:Disconnect Complete!			
		A07	12/31/09	08.57	010	0.125:Disconnect Complete!			
		A08	12/31/09	08.57	010	0.125:Disconnect Complete!			

You will notice that all lanes have" Disconnect Complete" in the Controller Traffic column

It is now possible to Exit the Software by using the Exit selector on the top left of the screen, or the X button on the top right



If this procedure is not carried out the software will inform the operator, that the program cannot be terminated, utilizing a message in the Controller Traffic column.

8	🗅 Edys-HSAUSA-1.8								
File	File Connection Exit								
1	BEST BY	BEST BY 12/31/09		DATE CO	DE ACTIVE	SEND WBAPPERS			
			8.40 LANE COL		E INACTIVE				
	STATUS	NAME	BEST BY	RUN TIME	OPTION FIELD	CONTROLLER TRAFFIC			
		A01	12/31/09	08.55	010	: Cannot terminate while conne			
		A02	12/31/09	08.55	010	: Cannot terminate while conne			
		A03	12/31/09	08.55	010	: Cannot terminate while conne			
		A04	12/31/09	08.55	010	: Cannot terminate while conne			

All of these options are available whether the Date Code is active or the Lane code is active. The active selection is always in green, as below.

Date Code Active



Lane Code Active



The only difference in any procedure is when the Lane Code is active the software does not need the operator to set the sell by date before sending the wrappers.

Sample Messages that are printed



Best By:11/18/09 Date Generated by software							
18-16	44 010	09.11	A01				
Factory Code (fixe	ed)	Run Time (updated by software every minute)					
	Line Number (variable in setup)	La	ne Number(variable in setup)				

Lane Code Message

A01		
Lane Number(variable in setup)		

These 2 messages are fixed within the Min Touch, and cannot be changed. If the message information is required to be changed, please contact Dartronics Technical Support.

Trouble Shooting the Connection between the Software and the Mini Touch units.

Normal Reasons for NO CONNECTIVITY

- 1) The MINI TOUCH is turned off
- 2) The IP address is set incorrectly
- 3) The Ethernet Cable (RJ45) is either disconnected or damaged.

Resolutions for this error

- 1) Turn ON the Mini Touch (The Screen should illuminate)
- 2) Check the IP address in the SET UP Screen matches that on the Mini Touch
- 3) Replace the Ethernet Cable

How to check the IP Address on the Mini Touch

