

## CB6e driver installation (Windows 7 32 bit)



- For CB6e-4 start from section 2.
  - For CB6e-8 and Pharma with CryptoBox USB dongle, start from section 1.
1. Installing the Crypto USB dongle.
    - a. Insert HSA USB stick.
    - b. Run CBUSetup.exe (d:\driver\CBUSetup\CBUSetup.exe).
    - c. Run the hsa.reg file (d:\hsa.reg).
    - d. Click "Yes" to continue.
    - e. Click "Ok" to have added information to the registry.
    - f. Plug in the CryptoBox USB dongle.
  2. Installing the Jungo driver as a legacy device (abbreviated).
    - a. Right click "My Computer" and select "Properties".
    - b. Select "Device Manager".
    - c. Click on "Action" and select "Add legacy hardware".
    - d. When prompted, browse to the Jungo driver (windrvr6.inf) and install it.
    - e. Stay in the Device Manager.
  3. Installing the CB6e driver (abbreviated).
    - a. Right click the PCI device and select "Update driver".
    - b. Browse to the CB6e driver (HSAJETCB.inf) and install it.

Now you should have installed the drivers needed for running with your CB6e board.

The driver also works with Windows XP 32 bit.