

Using PumpPRN as Pump10 replacements

1. Remove PumpPRN D21 green LED and connect wires from green LED in ink box, black and red wire must be correct.
2. Remove PumpPRN D17 red LED and connect wires from yellow LED in ink box, black and red wire must be correct.
3. Connect Purge button directly to Keyboard connector Pin 1 and 2
4. Optional – Connect red button to Keyboard connector Pin 1 and 3 (this is not necessary if you wish to use the black button to reset pumps)
5. Connect float sensors to FLOATHIGH and FLOATLOW
6. Connect pumps to K42 and K41, black and red wire must be correct.

