

MiniKey Firmware update via MiniDraw

Software:

MiniDraw.

Hardware:

Ethernet cable connection to MiniKey

1. Copy new firmware files (prom, sd_files, updatascript_MK.tsc) to locale directory.
2. Install latest MiniDraw version and Run MiniDraw program.
3. Press tools button and enter MiniKey network name (default is "HSAMK") or enter MiniKey ip-address acquired from MiniKey networks menu.
4. Press connect button and enter admin/1234 user/password if requested.
5. Press Firmware button (palm look-alike icon next to tools icon).
6. Select updatascript_MK.tsc and MiniDraw will start the scripted update of the MiniKey.
7. MiniDraw transfers new files and updates firmware...
8. Wait until MiniDraw says update done.
9. MiniKey will reboot and is updated when rebooted.